

Illustrated Parts List Model Series 32K400 GAS/KEROSENE


TYPE NUMBER(S)

0112.




PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	NO.	DESCRIPTION
	1 5 6		Cylinder Assembly Head-Cylinder Washer (Cylinder Head)	14 21		Stud (Cylinder Head) Cap-Oil Fill Gasket-Intake	870 871 1334		Seat-Valve (Exhaust) Bushing-Guide
	7 ★0	∕⁄692231	Gasket-Cylinder Head	215		Guide-Air	1004	092190	(Air Guide)
	8		Breather Assembly	306		Shield-Cylinder			(c.a.a.)
	9 ★	⊘ 27803s	Gasket-Breather	307	690294	Screw			
	10	690294				(Cylinder-Shield)			
		004540	(Breather Assembly)	308		Cover-Cylinder			
	11 13	691512 691614	Tube-Breather	322	692198	(Cylinder Cover)			
	13	091014	(Cylinder Head)	337	802592s	Plug-Spark			
			(1 3/4" Long)	383		Wrench-Spark Plug			
			Note	415	692882				
			691640 Screw			(Cylinder)			
			(Cylinder Head)	552	393666	Bushing-Governor			
Ι.	13A	691441	(2 1/16" Long) Screw	567	691104	Crank			
	13A	091441	(Cylinder Head)	367	091104	(Engine Base)			
			(2 7/16" Long)	591	691746	Plug-Camshaft			
			3 ,	626		Spacer-Governor			
						Crank			
ш			0 D (050						


<sup>Engine Gasket Set–Reference 358
Carburetor Overhaul Kit–Reference 121</sup>



RE No		PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	3		Seal-Oil (Magneto Side)	30		Dipper–Connecting Rod	593A	★270513	Gasket-Bearing Support
1	16	690536	Crankshaft	31		Lock-Rod Screw			(.015" Thick)
-	17	691938	Bearing-Ball	32	692345				Note
2	20	★691948	Seal-Oil			(Connecting Rod)			*270514 Gasket-
			(PTO Side)	33		Valve-Exhaust			Bearing Support
2	24	222698s	Key-Flywheel	34		Valve-Intake			(.010" Thick)
	25		Piston Assembly	35	691597	Spring-Valve			★270515 Gasket-
			(Standard)			(Intake)			Bearing Support
			Note	36	691597	Spring-Valve			(.005" Thick)
			390366 Piston			(Exhaust)	598	★270516	Shim-End Play
				40		Retainer-Valve			(.009" Thick)
			Assembly	42		Keeper-Valve			Note
؍ ا		000404	(.020" Oversize)	45		Tappet-Valve			★270517 Shim-End
4	26	390484	Ring Set	46		Camshaft			Play
			(Standard)	219		Gear-Governor			(.007" Thick)
			Note	221		Cup-Governor			★270518 Shim-End
			390505 Ring Set	225		Shaft-Governor Gear			Play
			(.020" Oversize)	228	691058				(.005" Thick)
2	27	691792	Lock-Piston Pin		000010	(Support Bearing)	742	691080	Retainer-Governor
2	28	299691	Pin-Piston	228A	690810				Shaft
			(Standard)			(Support Bearing)	743		Gear-Drive
			Note	553		Retainer-Valve Spring	746		Idler-Gear
			391286 Pin–Piston	571		Support-Bearing	755		Bearing-Camshaft
			(.005" Oversize)	571A	299705	Support-Bearing	900		Shaft-Gear
	29	299632	Rod-Connecting	500	.004044	(Magneto Side)	900A		Shaft-Gear
1			(Standard)	593	*091311	Gasket-Bearing	1141	690402	Washer
			Note			Support	4400	604.064	(Bearing Support)
			390306 Rod-				1190	691081	
							1001	600064	(Drive Gear)
			Connecting				1391	690301	Washer
			(.020" Undersize)						(Drive Gear)
			O-t D-f 050						


[★] Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121



REF NO.		DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	NO. 690946 *691948 281658	Plug-Oil Drain Seal-Oil (PTO Side) Cap-Oil Fill Gasket-Gear Reduction Cover	NO. 523	NO. 691352 *281370s 690622 294751 *691569	DESCRIPTION Dipstick Seal-Diptstick Tube Tube-Dipstick Base-Engine Gasket-Engine Base Clamp-Cable		NO. 691083 391361	


<sup>Engine Gasket Set–Reference 358
Carburetor Overhaul Kit–Reference 121</sup>



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
50 51 51B	27381	Manifold-Intake Gasket-Intake Gasket-Intake	102 104		Gasket-Carburetor Body Pin-Float Hinge	134 142 149	691966	Kit-Needle/Seat Nozzle-Carburetor Spring-Needle Valve
54	690953	(Carburetor) Screw (Intake Manifold)	107	391069	Body-Lower Carburetor Valve-Choke	150 176	691610	Gasket-Nozzle Seal-O Ring (Air Cleaner Base)
54A 90	691681 391065	` ,	108 109 110	691353	Shaft-Choke Washer	186 231	691764 691437	Connector-Hose
91 93 94	691769	Body Assembly-Upper Bushing-Throttle Shaft Kit-Idle Mixture	119	691587	(Upper to Lower	689 689A 701	691591	Spring-Friction Spring-Friction Retainer-Needle Valve
95 97	691437 691944	Screw (Throttle Valve) Shaft-Throttle	127 130		Carburetor Body) Plug-Welch Valve-Throttle	1146 1227	691587 99525s	Screw (Choke Shaft) Valve–High Speed
98 101		Kit-Idle Speed Pin-Shaft	132 133		Stop-Throttle Float-Carburetor			5 1


[★] Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
162 166	690267 691241	(Air Cleaner)	227	690545		614 616 626	291364	Pin-Cotter Crank-Governor Spacer-Governor
171	690284	(9 1/2" Long) Nut (Air Cleaner)	297 404	691331 690264	(Air Filter Retainer) Washer	643 668	691730 690313	•
203 205	690810	(Bell Crank)	445 467		Knob-Air Cleaner	967		(Governor Control Rod) Filter-Pre Cleaner
206		Nut-Governor Adjusting Rod-Governor Control	505	691251	Nut (Governor Control Lever)	968	691755	Cover-Air Cleaner
209 212		Spring-Governor Link-Throttle	536 562	391063 691119	Cleaner-Air Bolt (Governor Control Lever)			

<sup>Engine Gasket Set–Reference 358
Carburetor Overhaul Kit–Reference 121</sup>




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
179 180 181	690280 392887	(Fuel Tank Strap) Tank-Fuel (No Longer Available) Cap-Fuel Tank	210 240 240A 245 246	298090s 690612 *692190 298683	Screen-Filter Filter-Fuel Filter-Fuel Gasket-Fuel Bowl Bowl-Fuel Filter Yoke-Bowl	707 889 917	690279 93915 691737	(Fuel Tank Strap)
181A	392886	(Large) (Kerosene Only) Cap-Fuel Tank (Small) (Gas Only)	247 450 601 670	691075 95162 690505	Washer (Fuel Tank Bracket) Clamp-Hose Spacer-Fuel Tank			
182 182A 183 186 186A 187	691937 691764 691609 791893	Bracket-Fuel Tank Strap-Fuel Tank Connector-Hose	674	690303	Screw (Fuel Tank Bracket)			
137A	191143	(Cut to Required Length)						

<sup>Engine Gasket Set–Reference 358
Carburetor Overhaul Kit–Reference 121</sup>



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23	395251	Flywheel	331	691075	Washer	725	690420	Shield-Heat
		(Magnetron)			(Booster Fan)	726	391362	Gear-Ring
		Note	332	691059	Nut	773	690265	Retainer
		391363 Flywheel			(Flywheel)	823	691108	Screw
73	691171	Screen-Rotating	363	19203	Puller-Flywheel			(Muffler Adapter)
74	691655	Screw	440	691076	Screw	834	691075	Washer
		(Rotating Screen)			(Booster Fan)			(Muffler Adapter)
81	691178	Lock-Muffler Screw	458	69932	Kit-Rope/Handle	863	694016	Bracket-Muffler
264	691105	Nut	613	691416	Screw	864	394584	Adapter-Muffler
		(Muffler Adapter)			(Muffler)	864A	690637	Adapter-Muffler
298	691808	Locknut-Muffler	676	393761	Deflector-Muffler	883	★692236	Gasket-Exhaust
300	399635	Muffler	677	690661	Screw	944	691690	Stud
321	691151	Fan-Booster			(Muffler Deflector)			(Muffler Adapter)


<sup>Engine Gasket Set–Reference 358
Carburetor Overhaul Kit–Reference 121</sup>



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
197 304 305	90072 391229 690297	Screw (Back Plate) (5/8"Long) Housing-Blower Screw (Blower Housing)	384 405 452	690371 690290 92864	Washer (Back Plate) Screw (Back Plate) Washer (Back Plate)	732 736 851 877 878	493880s 393456	Screw (Starter Drive Cover) Nut-Clip Terminal-Cable Wire-Alternator Harness-Alternator
305A 316	690290 691612	(7/16" Long) Screw (Blower Housing) (1/2" Long) Nut	452A	26404	(Lockwasher) Washer (Back Plate) (Flat)	888 A888	690292 690295	Screw (Insulator) (1/2" Long) Screw (Insulator)
333 334	398811 691061	(Back Plate) Armature–Magneto Screw (Armature)	474 507 573		Alternator (Dual Circuit) Insulator Plate–Back	895 1059	692309 698516	(3/8" Long)
356 359	690650 691077	Wire-Stop Washer (Insulator)	588 589	690375 690300	Bracket–Armature Screw (Armature Bracket)	1119	691183	Screw (Alternator)
367	690305	Screw (Clip Wire)	727 729	692338 690432	Cover-Starter Drive Clip-Wire			
379	691612	` '	729A	690588	(Alternator) Clip-Wire			


Engine Gasket Set-Reference 358


Carburetor Overhaul Kit-Reference 121




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
NO. 309 310 311 442 503 510 513 544	396306 692329 497608 691693 690406 696541 692024	Motor-Starter Bolt (Starter Motor) Brush Set	NO. 668A 675 697 727 732 783 797	396515 691261 691058 692338 93410	Spacer (Starter Motor) Washer (Brush Retainer) Screw (Starter Motor) Cover-Starter Drive	NO. 801 802 803 1051 1090	394802 691286 691265	Cap-Drive Cap-End Housing-Starter (Serviced By 396306 Starter Motor Only) Ring-Retaining Retainer-Brush

<sup>Engine Gasket Set–Reference 358
Carburetor Overhaul Kit–Reference 121</sup>







REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3 7	291675s 692231	Seal-Oil (Magneto Side) Gasket-Cylinder Head	245 358 399	299719	Gasket-Fuel Bowl Gasket Set-Engine Gasket-Counterweight	593 593A		Gasket-Bearing Support Gasket-Bearing
9 20	691948	Gasket-Breather Seal-Oil (PTO Side)	524 569		Cover Seal-Dipstick Tube Gasket-Engine Base			Support (.015" Thick) Note
51 51B 94 102	692214 292681	Gasket-Intake Gasket-Intake Kit-Idle Mixture Gasket-Carburetor						*270514 Gasket- Bearing Support (.010" Thick) *270515 Gasket-
104 121		Body Pin-Float Hinge Kit-Carburetor Overhaul				598	270516	Bearing Support (.005" Thick) Shim-End Play (.009" Thick)
127 134 142	394682	Plug-Welch Kit-Needle/Seat Nozzle-Carburetor						*270517 Shim (.007" Thick)
						883 1095		*270518 Shim (.005" Thick) Gasket-Exhaust Gasket Set-Valve

[★] Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121